

XB2 Pilot Light & Pushbutton 按钮开关



XB2-ER42



XB2-ES542



XB2-ET42



XB2-ES142



XB2-ED21



XB2-ED33



XB2-EJ21



XB2-EJ33



XB2-EG33



XB2-EW3361



XB2-EW8465

Description	Contact Type	Supply voltage	Color	Reference
Mushroom head	N/O	250V	Black	XB2-ER21
		50/60Hz	Green	XB2-ER31
	N/C		Red	XB2-ER42
Turn to release	N/C		Red	XB2-ES442
			Red	XB2-ES542
			Red	XB2-ES642
Push-pull Red	N/C		Red	XB2-ET42
			Red	XB2-EX42
Turn to release Red release (Key n°445)	N/C		Red	XB2-ES742
			Red	XB2-ES142
			Red	XB2-ES242
2 position	N/O			XB2ED21
				XB2ED25
				XB2ED41
				XB2ED45
3 position	2N/O			XB2ED33
				XB2ED53
				XB2ED73
				XB2ED83
				XB2ED21
2 position	N/O+N/C			XB2EJ21
				XB2EJ25
				XB2EJ41
				XB2EJ45
3 position	2N/O			XB2EJ33
				XB2EJ53
				XB2EJ73
				XB2EJ83
				XB2EJ21
2 position	N/O+N/C			XB2EG21
				XB2EG25
				XB2EG41
				XB2EG45
				XB2EG61
3 position	2N/O			XB2EG65
				XB2EG33
				XB2EG53
				XB2EG03
				XB2EG73
Direct bulb supplied	N/O		White	XB2-EW3161
			Green	XB2-EW3361
			Yellow	XB2-EW3561
			Blue	XB2-EW3661
			Red	XB2-EW3462
Via integral resistor Ba9s, LED 24V bulb supplied	N/O		White	XB2-EW3171
			Green	XB2-EW3371
			Yellow	XB2-EW3571
			Blue	XB2-EW3671
			Red	XB2-EW3472